

Things to Keep in Mind When Creating Creform Devices:

Common Problems:

1. Make sure that you are recording clear pipe length specifications. Example: 2, 34” pipes, 1, 21” pipe, etc.
2. Handwritten notes are often difficult to read later. Be sure that you or someone on your team is able to read your notes!

Before you leave the worksite for the day, provide:

1. a “before” scenario that describes how the problem(s) was dealt with before the implementation of the Creform device.
2. a *complete* parts list with clear pipe length specifications
3. A brief product description
4. Pictures of the device (if possible!)